How to get Gas & Electricity Meter Readings from your Freedom Unit

Freedom Unit

Duel Fuel Supply

Gas - Press 2 11 times

Electricity - Press 1 11 times

Electricity Only Supply

Press 9 once

entity
Dual Fuel Freedom
XXXXX
PMR100-272
1 2 3
4 5 6
7 8 9
* 0 #
How To Key In The Vend Code
(1) Press the '*' key.
(2) Press button '1' for Electricity or '2' for Gas.
(3) Enter the Vend Code carefully via the numeric keypad.
(4) Correct errors by pressing '*'.
(5) When complete, press the '#' button to confirm.
For help on displays see booklet.

Meter Reading!

...or directly from the meters

Electricity Meter Reading!

Gas Meter Reading!

Press 4 once

utilita
pre-pay the smart way